



NEUTRALISING ALL SURFACES AFTER USING PEEL AWAY 1

- 1) ALL SURFACES MUST BE THOROUGHLY WASHED WITH WATER.
- 2) PEEL AWAY 1 is an Alkaline stripper, after removal of the laminated sheets with paint and paste, the surface is left with a residue.
- 3) This loose and softened residue needs to be removed with damp sponges and contained.
- 4) Lightly wet the surface, using a nylon brush or broom, scrub the surface to remove any excess residue.
- 5) Thoroughly rinse the surface with water using sponges for interior, a hose, light pressure cleaner or steam cleaner for exterior. Some porous surfaces like wood may need to be washed more than once.
- 6) After the surface has dried the surface must be NEUTRALISED.
Use PEEL AWAY Neutraliser concentrate (acetic acid) or a few applications of household white vinegar if the concentrate is not available.
- 7) Apply neutraliser and leave on for six to eight hours . Rinse off with plain water. On wood if a dry white powder appears, dry brush and reneutralise.
- 8) Prior to PAINTING OR RECOATING surfaces should always be dry and pH test should be done on the surfaces if uncertain.
- 9) On porous surfaces like certain woods, moisture can take a long time to dry out, sometimes up to 60 days.
- 10) Always use a good quality sealer binder under coat.

PEEL AWAY AUSTRALIA – ASIA PACIFIC PTY LTD
ACN: 146 029 469
Unit 43 Homebush Business Village
11-21 Underwood Road, Homebush NSW 2140
Ph: 02 9746 7755 Fax: 02 9746 5322
Website Address: www.peelaway.com.au