



AM-BOSS

ACCESS LADDERS PTY LTD

A.B.N. 23 007 214 959



11-13 MAIDA AVENUE, NORTH SUNSHINE, 3020. AUSTRALIA
TEL:(03) 9310 8788, (03) 9366 0899 FAX: (03) 9367 9673
INTERNATIONAL TEL: +61 3 9310 8788 +61 3 9366 0899 FAX: +61 3 9367 9673
EMAIL: amboss1@bigpond.com WEBSITE: www.ambossaccessladder.com.au

AM-BOSS Access Ladders are CodeMark Certified

OPERATING AND MAINTANANCE PROCEDURE ON AM-BOSS ACCESS LADDERS.

AM-BOSS Access Ladders work on a reliable counter balance spring system.

OPENING

Engage hook on pole (supplied) into small eyelet on opening end of ceiling access panel. Gently pull door open till it comes to rest against the stops on the adjusting mechanism. No need to unhook the pole from the panel. Firmly grab ladder section (with rubber feet) with both hands and, stepping backwards, unfold and extend the ladder to the floor.

CLOSING

With both hands lift up bottom section of ladder and fold back up on top of each other. With the use of the pole gently first push, then ease panel back up till it is fully closed. The spring counter balance system will keep the panel shut.

MAINTENANCE

ALL MOVING PARTS ARE FACTORY PRE-LUBRICATED AND LUBRICATION SHOULD NOT BE REQUIRED FOR SOME TIME. HOWEVER SHOULD OPERATION OF THE UNIT BE IN EXCESS OF 3 TO 5 TIMES A DAY, ALL MOVING PARTS MUST BE LUBRICATED ONCE EVERY TWO MONTHS. MOST IMPORTANT IS THE LUBRICATION OF THE PIVOT POINT OF THE LINKAGE-ARMS JOINED TO THE SIDE PLATE WITH THE ADJUSTING SYSTEM. THIS PART DOES MOST OF THE WORK.

**INSPECTION OF THE WHOLE SYSTEM SHALL BE
CARRIED OUT ONCE A YEAR AND ACTION TAKEN.**

MANUFACTURERS OF CEILING LADDERS FOR DOMESTIC COMMERCIAL AND INDUSTRIAL APPLICATIONS

- Many Stock Sizes On Hand • Special Size Hatches Made To Order • Ladders Made To Any Ceiling Height • Escape Stairs • Electric Stairs •
- Many Options & Accessories • Easily Installed By One Person • Professional Installation Available Including In Suspended Ceilings •

ORIGINATION DATE: 24 February 2004

AUTHOR: Werner Hecht

CONTROLLED COPY NO.: 1 2 3

T:\Operation & Maintanance\Controlled\om1operation inst and maintanance am-boss ladders_130920_RevC.doc