

# **REDSTAR** TLW-230ES



## **SPECIFICATIONS**

#### DC WELDING POWER

Rated Output (kW) 5.6
Rated Current(A) / Voltage(V) / Duty(%) 200 / 28 / 50
Welding Current Range (A) 50~230

#### AC POWER SOURCE

Frequency (Hz) 50 / 60 Rated Output (kVA) 5.0 / 5.5

Rated Voltage (V) 100 / 110 / 120 / 200 / 220 / 230 / 240

No. of Phase 1-Phase, 2 Wire

Power Factor 1.0

#### DIESEL ENGINE

Make / Model Kubota Z482-K2A

Type 4-cycle, vertical, water cooled with radiator

 Rated Output (kW)
 9.6

 Rated Speed (min<sup>-1</sup>)
 3600

 Displacement (L)
 0.479

Fuel ASTM No. 2 diesel fuel or equivalent

Fuel Consumption (L/h) 1.6
Fuel Tank Capacity (L) 19
Battery x Quantity 36B20Lx1

#### UNIT

Length / Width / Height (mm) 1220 / 610 / 720

Dry Weight (kg) 28

# NOISE

7mdB (A) 60 / 63

#### **CLEAN ENGINE**

The engine equipped with the Closed Breathing System which keeps the blow-by gas in the machine, and the aluminium radiator which does not cause lead pollution is categorised as a construction machine that satisfies the emission gas regulation stage 2, enforced by the Ministry of Land, Infrastructure and Transport (except for DAW-180SS).

#### SLOWDOWN DEVICE REDUCES NOISES AND SAVES

The Slowdown unit automatically lowers engine speed during no-load, reducing noise and increasing fuel efficiency.

#### **EASY DAILY INSPECTION & MAINTENANCE**

Daily inspection and maintenance can be carried out one side of the machine. In addition, the radiator can be cleaned easily by removing the front cover.

# SWITCH KEY OPERATION RESTARTS THE ENGINE WITH AIR VENTED AUTOMATICALLY

The generator is equipped with an automatic airventing unit that eliminates air by turning a switch key when restarting the engine after fueling.

### ALTERNATOR REQUIRES MAINTENANCE FREE

The use of brushes or slip rings in the alternator eliminates the need for maintenance.

### VARIOUS PROTECTIVE SYSTEMS ASSURING SAFETY

This machine

- automatically cut the power off when over-loading DC output. (except for TLW-230ES)
- protect over-loading AC output by shutting down its circuit breaker.
- automatically stop the engine with the warning indicators, at low lube oil pressure, high water temperature, and insufficient charging of the battery.
- prevent from electrical leaking with its relay. (optional for DAW-180s. DAW-300SS. TLW-230S)

#### OPTIONS

Four-wheel kit, exhaust pipe attachment, remote controller, measures against salt damage.